


Keyboard Connector

Joystick and sequencer switch wiring



Top
Keyboard
Cinch Jones
Female

1	2
3	4
5	6
7	8

- *1 = Input Ch. 1
- 2 = -9V d.c. to C7
- 3 = 0V d.c.
- 4 = +12V d.c. to C9
- 5 = Keyboard Trigger
- *6 = Input Ch. 2
- 7 = Meter
- 8 = Sequencer ON/OFF

Viewed from solder side
* 100K Resistor in Series Ch.I and Ch.II

Sage Music Electronics

Joystick & Sequencer wiring

Derek G Revell

Rev 1.1
25/11/2013

Page 4 of 5